



Applying Your Custom Pole Pad Lettering



Step 1:

Make sure you are within 40°F-100°F then clean the surface of the padding with a generous amount of **Isopropyl Alcohol** (aka Rubbing Alcohol) and a **paper towel**.



Step 2:

Slowly and carefully remove the white backing paper from the clear transfer tape. As you peel, make sure that each letter adheres to the clear transfer tape.



Step 3:

With one end of the sticker in each hand, hold up to the pad while another person ensures the letters are square and straight. Once the letters are in the desired position, apply pressure, starting from the top working your way down slowly, pressing firmly on each letter.

Wait 20 minutes to allow the glue to start to cure. The glue is pressure activated.



Step 4:

After 20 minutes, slowly peel the clear transfer tape off of the pole padding as shown in the photo.

If a letter does not stick to the pole padding, use the transfer tape to firmly apply pressure to the letter and then retry.